

# How to install ReActiv 1.7



Geocentrix Ltd

Scenic House  
54 Wilmot Way  
Banstead  
Surrey  
SM7 2PY  
United Kingdom

www.geocentrix.co.uk  
mail@geocentrix.co.uk  
Tel: +44 (0)1737 373963  
Fax: +44 (0)1737 373980

Managing Director  
Andrew Bond  
MA MSc PhD DIC MICE CEng  
andrew.bond@  
geocentrix.co.uk

Registered office  
as above

Registered in England  
No. 3738829

VAT Registration No  
GB 709 3785 07

Geocentrix is a registered  
trademark of Geocentrix Ltd

1. Connect the supplied security key (a.k.a. dongle) to your computer's USB port.
2. Place the Geocentrix Software CD in your CD-ROM drive. The Browser should automatically appear (if not, run **SETUP.EXE** from the CD's root folder).
3. Click on the text "**Click here to install ReActiv**" to run the ReActiv setup program.
4. When asked "Do you want to run or save this file?" click **Run**. If a security warning appears, click **Run**.
5. When the welcome screen appears, read the instructions and click **Next**.
6. Read and accept the License Agreement and click **Next**.
7. Read the program's 'readme' file and click **Next**.
8. Select which features to install, choose the installation path, and click **Next**.
9. Click **Next** to install the application and **Finish** when setup is complete.
10. The HASP Device Driver setup program will then start to install the drivers necessary for ReActiv to communicate with its security key. This process may take some time – if so, please be patient. When the HASP setup is complete, ReActiv will start automatically.



11. When ReActiv 1.7 first runs, you will be prompted to register the program. Choose the Product, enter your Company Name, PIN, and Licence exactly as given on the label attached to the security key and click **OK**. (For perpetual licences, leave the Expires box unticked.)

To learn how to use the program, we suggest you follow Tutorials 1-3 in the program's *User Manual* (available in Adobe PDF format from the program's **Help** menu).