

How to install ReActiv 1.6



Geocentrix Ltd

Scenic House
54 Wilmot Way
Banstead
Surrey
SM7 2PY
United Kingdom

www.geocentrix.co.uk
mail@geocentrix.co.uk
Tel: +44 (0)1737 373963
Fax: +44 (0)1737 373980


Managing Director
Andrew Bond
MA MSc PhD DIC MICE CEng
andrew.bond@
geocentrix.co.uk

Registered office
as above

Registered in England
No. 3738829

VAT Registration No
GB 709 3785 07

Geocentrix is a registered
trademark of Geocentrix Ltd

1. Place the Geocentrix Software CD in your CD-ROM drive. The Browser (right) should automatically appear (if not, run **SETUP.EXE** from the CD's root folder).
2. Click on the text "**Click here to install ReActiv**" or the arrow  alongside it to run the ReActiv installation program.
3. When asked "Do you want to run or save this file?" click **Run**. If a security warning appears, click **Run**.
4. When the welcome screen appears, click **Next**.
5. Read and accept the License Agreement and click **Next**.
6. Review the release notes and click **Next**.
7. Select which features to install and choose an install path, then click **Next**.
8. When you are ready to update your system, click **Next**. The ReActiv Setup program will install the necessary files on your system.
9. When setup is complete, click **Finish**. The HASP Device Driver setup program will then start, allowing you to install the drivers necessary for ReActiv to communicate with its security key. Select a language and click **OK**. Then follow the on-screen instructions.
10. When the HASP setup is complete, click **Finish**. If you ticked the **Run ReActiv** box, ReActiv will start automatically.
11. To register your copy of ReActiv, click **Help > Licence Registration Wizard** from the program's main menu. Enter your details exactly as found on the program's packaging. Make sure the supplied security key is attached to your computer and click **Register** to run ReActiv. (To run a trial edition of ReActiv, click **Trial**.)

To learn how to use the program, we suggest you follow Tutorials 1-3 in the program's User Manual (available in Adobe PDF format from **Start > All Programs > Geocentrix > User Manuals > ReActiv 1.6 User Manual**).

